



# PICNIC BASKET





## Picnic Basket

NB WITH CUTLERY HCF-74028  
FULL WILLOW AND  
WOODCHIP PICNIC BASKET  
FOR 2 PERSON USE

L-40 x W-28 x H-19 CMS







## Picnic Basket

NB WITH CUTLERY HYT-53601  
WILLOW PICNIC BASKET FOR  
2 PERSON USE

L-36 x W-27 x H-19 CMS







## Picnic Basket

NB WITH CUTLERY HST-64002  
WILLOW AND WOODCHIP  
PICNIC BASKET FOR 2 PERSON  
USE

L-40 x W-28 x H-20 CMS







## Picnic Basket

NB WITH CUTLERY HZF-73003  
WILLOW PICNIC BASKET FOR  
2 PERSON USE

L-30 x W-30 x H-19 CMS





## Picnic Basket

NB WITH CUTLERY HCF-73802  
WILLOW AND WOODCHIP  
PICNIC BASKET FOR 2  
PERSON USE

L-38 x W-26 x H-19 CMS







## Picnic Basket

NB WITH CUTLERY HQC-1682  
WILLOW PICNIC BASKET FOR  
2 PERSON USE

L-40 x W-30 x H-20 CMS



## Picnic Basket

NB WITH CUTLERY HST-74014  
WILLOW PICNIC BASKET FOR  
4 PERSON USE

L-44 x W-29 x H-23 CMS







## Picnic Basket

NB WITH CUTLERY OD 0036  
WILLOW AND WOODCHIP  
PICNIC BASKET FOR 4  
PERSON USE

L-40 x W-28 x H-22 CMS





## Picnic Basket

NB WITH CUTLERY HCF-74020  
FULL WILLOW AND  
WOODCHIP PICNIC BASKET  
FOR 4 PERSON USE

L-40 x W-28 x H-20 CMS







## Picnic Basket

NB WITH CUTLERY HCF-74008  
WILLOW AND WOODCHIP  
PICNIC BASKET FOR 4  
PERSON USE

L-40 x W-28 x H-20 CMS



**THANK YOU**

